



Critical Usage Information

Clear Spa 104 Cartridge Cleaner

The following is only basic usage directions. Refer to the actual product label for First Aid, Warnings and other statements of use.

Cartridge Cleaner removes oil, scale, organics and grime from cartridge filters. Regular use with Cartridge Cleaner increases water flow and helps keep the water cleaner, with maximum efficiency. Compatible with chlorine, bromine, biquanide, copper / silver, and ozone treated spas. Regular use of Cartridge Cleaner increases filter cycle.

DIRECTIONS

Shake thoroughly before using.

FOR CARTRIDGE FILTERS

Remove cartridge from filter and squirt filter from top to bottom with Cartridge Cleaner and allow to stand for 5 minutes or until foaming action stops. For deep cleaning, cartridges can be placed in a large plastic bag, tied closed, and set in a warm area for 30 minutes. Then, rinse and replace grids in filter and continue normal operation.